

21-23 F150 Tail Light Conversion

Forscan Changes (Original -> New Value) SAVE YOUR ORIGINAL AS-BUILT

- BdyCM (**HyperFlash Fix**)
 - 726-43-01 xxxx-xxxx-**01**xx
 - 726-43-02 **0102-02**xx-xxxx
 - 726-44-02 **00**xx-xxxx-xxxx

**Only change below if you have BLIS
RELATED DTC's**

- SODL (**Blind Spot Fix**)[PART 1]
 - Open SODL Module (As-Built Configuration)
 - Click “Load Factory Asbuilt”
 - Write ALL!
- SODR(**Blind Spot Fix**)[PART 2]
 - Open SODR Module (As-Built Configuration)
 - Click “Load Factory Asbuilt”
 - Write ALL!