


## 2024+ Ford F-150 HSW Harness Installation Guide

New SCCM & HVAC Controls May be Required. [VERIFY FITMENT.](#)

- **NL3Z-19980-S** (HVAC Controls W/ HSW button)
- **SL3Z-3F791-BA** (SCCM W/HSW function)




**Plug in the HSW connector behind the SCCM(C226B)**

→ Route the harness across the dash to the passenger side.  
Follow the original dash harness and use plenty of zip ties.



## Locate the Central Junction Box

Locate the CJB(aka Fuse Box) on the passenger side footwell.



## Locate the CJB Connector(C270B)


Once unlatched disassemble the connector and add the wire to **PIN 1**.



**\*\*IMAGE IS THE FRONT OF CONNECTOR\*\***

## Ground the shorter wire(G201)

Locate the grounding bolt on the driver side footwell. Ground the terminal ring here.



Contact [support@midnightoem.com](mailto:support@midnightoem.com) to inquire about our remote programming option. **Subject to software cost & refundable deposit for hardware.**

## Forscan Changes (Original -> New Value) **SAVE YOUR ORIGINAL AS-BUILT**

- **APIM**

- **7D0-02-01 xxxx-0xxx-xxxx**

<i>0 to 1</i>	<i>2 to 3</i>	<i>4 to 5</i>	<i>6 to 7</i>
<i>8 to 9</i>	<i>A to B</i>	<i>C to D</i>	<i>E to F</i>

- **7D0-02-02 x0xx-xxxx-xxxx**

<i>0 to 2</i>	<i>1 to 3</i>	<i>4 to 6</i>	<i>5 to 7</i>
---------------	---------------	---------------	---------------

- **7D0-03-02 00xx-xxxx-xxxx (MAY NOT BE NEEDED)**

***0B(F150) to 10(SUPER DUTY)***

**CHOOSE SUPER DUTY IF INSTALLING CLIMATE CONTROLS WITH HSW BUTTON**

- **IPC**

- **720-05-02 0xxx-xxxx-xxxx**

<i>0 to 1</i>	<i>2 to 3</i>	<i>4 to 5</i>	<i>6 to 7</i>
---------------	---------------	---------------	---------------

- **SCCM**

- **724-01-01 xxxx-8xxx-xxxx**
  - **724-06-01 Bxxx-xxxx-xxxx**
  - **724-06-01 x0xx-xxxx-xxxx**

- **HVAC**

- **733-01-02 xxx0-xxxx-xxxx**

<i>0 to 8</i>	<i>1 to 9</i>	<i>2 to A</i>	<i>3 to B</i>
<i>4 to C</i>	<i>5 to D</i>	<i>6 to E</i>	<i>7 to F</i>



## FDRS INSTRUCTIONS!

Contact **[support@midnightoem.com](mailto:support@midnightoem.com)** to inquire about our remote programming option. **Subject to software cost & refundable deposit for hardware.**

- 1. MUST HAVE A J2534 ADAPTER!!**
- 2. Download [FDRS\(Dealer Software\)](#)**
- 3. Purchase FDRS License (\$120)**
- 4. Install the application & launch**
- 5. Log into Ford Account**
- 6. Begin by connecting the adapter and clicking  
“Go” to read vehicle data.**
- 7. Once vehicle data has been read & downloaded  
search in the ToolBox tab for “TRON”**
- 8. Click “Download” to download the tool and then  
run.**
- 9. Amongst the options click “Diagnose & Repair”**
- 10. Once the process is complete without errors!!  
then close the application, if it fails or has errors  
run again!**